

Tools Required: Pisheed screwiriver, Philips screwiriver, pliers, wire cutters, wire shippers, electrical laps, safety plasses.

Light Scarce: (1) 1287 LED YW DEMARK F (4000).

Estimated Assurably Time: 15-30 minutes

Properation: Identify and impost all parts before beginning installation. Check package content list and diagrams below to be sure all parts are present. If any parts are missing or duraged, do not attempt to assumble, install, or operate the tidure. Content customer service for replacement nexts.

▲ Warnings and Cautions

Turn off electricity at circuit breaker or main fuse box before treballation. Consult a Scanced electricism if in doubt.

These instructions are provided for your safety, it is very treportant you read them completely before treballing the focuse.

We strongly recommend that a Sceneed, professional electricism perform the treballion.

Discorned fidure from power source before replacing bulbs. Make sure bulbs are given aufficient time to cool before removal.



