

Installation Instructions

NMP-AREC

Recessed Flange Accessory for Josh Adjustable LED Puck Light

READ PRIOR TO ATTEMPTING INSTALLATION
ALWAYS TURN OFF MAIN POWER BEFORE INSTALLATION
INSTALLATION SHOULD BE CARRIED OUT BY YOUR LOCAL ELECTRICIAN

⚠ IMPORTANT - This equipment is intended to be installed only by qualified personnel. The installation must be made in accordance with the current edition of the National Electrical Code and all applicable state and local building codes. The final installation must be approved by the appropriate, qualified electrical/building inspector(s). Improper installation may result in a fire or electrical hazard. Be sure the electrical power to the circuit has been disconnected before installing this electrical system.

⚠ IMPORTANT - Cet équipement est destiné à être installé uniquement par du personnel qualifié. L'installation doit être faite conformément à l'édition actuelle du Code national de l'électricité et à tous les codes de construction locaux et nationaux applicables. L'installation finale doit être approuvée par un ou plusieurs inspecteurs qualifiés en électricité / bâtiment. Une installation incorrecte peut entraîner un incendie ou un risque électrique. Assurez-vous que l'alimentation électrique du circuit a été déconnectée avant d'installer ce système électrique.

INSTALLATION

- Layout the luminaire(s) to determine length to power line interconnect (ordered separately: [NMPA-6P-24](#)). Each luminaire includes a 72" low voltage wire with quick connect, extension cables are available.
- Up to three luminaires may be installed in an enclosed cabinet size: 3.5" x 11.5" x 12"
- Ensure electrical power is off.
- 1. Remove puck (ordered separately: NMP-A) from surface mount body to use with recessed flange accessory. (Figure 1)
- 2. Route the puck wires through the furthest slot of the recessed flange.
Optional: Attach cover plate with screws (included). (Figure 2)
- 3. Place puck slots over the ball blungers and insert into place. (Figure 3)
- 4. Determine mounting position and cut 3.15" diameter hole in mounting surface. (Figure 4)
Note: Puck light rotates on axis of ball plungers.
- 5. Insert luminaire and wires through cut out until flange is flush with surface. (Figure 5)
- 6. Adjust luminaire to desired angle and pull excess wire if needed. (Figure 6)
- 7. Connect 72" low voltage wires to power line interconnect ([NMPA-6P-24](#)). (Figure 7)
- 8. Connect power line interconnect to compatible 12V LED driver (ordered separately).

REQUIRES: NMP-A (Ordered Separately)
[NMPA-6P-24 \(Ordered Separately\)](#)

