



## WHAT'S IN THE BOX

- Microwave Sensor

## WHAT YOU'LL NEED (NOT INCLUDED)

- Wire Cutters
- Wiring supplies as specified by electrical code
- Wire nuts/Wago Connectors

## INSTALLATION INSTRUCTIONS

For use with:

### **MS1-DHR-KO-1:**

Premise LED  
LHB3 "-1"  
LHB3 "-3" (120-277V only)  
CS3 (120-277V only)  
VP2 (120-277V only, 4ft only)  
VPHB1 (120-277V only)

### **MS1-DHR-KO-4:**

Premise LED  
LHB3 "-2" (347-480V only)  
LHB3 "-3" (347V only)  
CS3 (347V only)  
VP2 (347V only, 4ft only)  
VPHB1 (347V only)

## IMPORTANT

Before installing this sensor, please make sure that you carefully read through this instruction sheet. Consider having this sensor installed by a qualified licensed electrician.

Refer to spec sheet for how to program.

**Premise LED Inc.**  
80-86 Carrier Drive  
Toronto, ON Canada  
M9W 5R1  
PREMISELED.COM

# MS 1-DHR-KO-1/4

## INSTALLATION INSTRUCTIONS

### TO INSTALL THE SENSOR

1. For the LHB3, remove screws on driver cover plate. For the CS3, remove screws on the end cap, slide the lens out, then remove the screws on the chip board.
2. Pick which location on the fixture you'd like to install the sensor. For LHB3, the sensors can be installed on the ends. On the CS3, refer to the to the spec sheet for knockout locations.
3. Remove the knockout.
4. Unscrew the lock nut that's attached to the sensor.
5. Feed the sensor's cord through the knockout hole, then re-attach the lock knock securely.
6. Connect the wires according to the wiring diagram below.

