

WARNINGS



RISK OF FIRE, ELECTRICAL SHOCK, CUTS OR OTHER CASUALTY HAZARDS

Installation and maintenance of this product must be performed by a qualified electrician. This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and hazards involved.

RISK OF FIRE AND ELECTRIC SHOCK

Make certain power is OFF before starting installation or attempting any maintenance. Disconnect power at fuse or circuit breaker.

RISK OF FIRE

Refer to product label for specific minimum supply conductor requirements.

RISK OF BURN

Disconnect power and allow fixture to cool before handling or servicing.

RISK OF PERSONAL INJURY

Fixture may become damaged and/or unstable if not installed properly.

DISCLAIMER OF LIABILITY: CSC LED assumes no liability for damages or losses of any kind that may arise from the improper, careless, or negligent installation, handling or use of this product.

NOTICE: Green ground wire provided in proper location. Do not relocate.

SAFETY: This fixture must be wired in accordance with the National Electrical Code and applicable local codes and ordinances. Proper grounding is required to insure personal safety. Carefully observe grounding procedure under installation section.

APPLICATIONS: This lighting fixture is designed for outdoor lighting services, and should not be used in area of limited ventilation or inside high ambient temperature enclosures. It must be stored in a dry location prior to installation. Do not expose lighting fixture to rain, dust or other environmental conditions prior to installation and insertion of photo control or shorting cap (if so equipped). Best results will be obtained if installed and maintained according to the following recommendations.

ATTENTION RECEIVING DEPARTMENT: Note actual fixture description of any shortage or noticeable damage on delivery receipt. File claim for common carrier (LTL) directly with carrier. Claims for concealed damage must be filed within 15 days of delivery. All damaged material, complete with original packing must be retained.

PRIOR TO INSTALLATION

IMPORTANT: Apply a bead of silicone to the top and side of the fixture where it meets the wall or mounting surface to prevent water ingress from the back of the fixture. **FAILURE TO DO SO WILL VOID WARRANTY.**

INSTALLATION INSTRUCTIONS

1. Unscrew both sides of the luminaire and remove the mounting plates (Fig. 1.1).
2. Affix the mounting plate to the junction box with the screwdriver (Fig. 1.2).
3. Connect the wires (L,N,G) to the power supply. Please cap the dimming cables if not in use (Fig. 1.3).
4. Mount the luminaire to the mounting plate and secure it with the supplied nut (Fig. 1.4).




Fig. 1.1




Fig. 1.2




Fig. 1.3




Fig. 1.4

PLEASE ENSURE THAT THE LUMINAIRE IS CORRECTLY WIRED AND INSTALLATION IS COMPLETE BEFORE TURNING THE POWER SWITCH ON.

WATTAGE AND COLOUR SELECTABLE SWITCH

IMPORTANT: TURN OFF THE POWER BEFORE ADJUSTING POWER AND COLOUR TEMPERATURE.

1. The power and colour temperature switch is located on the side of the luminaire. Remove the plug to access the switch (Fig. 2.1).
2. After adjusting to your desired setting, please put the plug back in place and tighten it.




Fig. 2.1

PHOTOCELL INSTRUCTIONS

The luminaire comes pre-installed with a photocell (Fig. 3.1). If the photocell is not needed, unplug the wires connected to the photocell (Fig. 3.2).

In order to unplug the photocell, you will need to access the luminaire's driver compartment (Fig. 3.3 and Fig. 3.4).

NOTE: WCYL-RGBW-30W-LV does not come with the photocell.




Fig. 3.1




Fig. 3.2




Fig. 3.3




Fig. 3.4