

Installation Instructions

NT-327

Outlet Adapter

READ PRIOR TO ATTEMPTING INSTALLATION
ALWAYS TURN OFF MAIN POWER BEFORE INSTALLATION
INSTALLATION SHOULD BE CARRIED OUT BY YOUR LOCAL ELECTRICIAN

⚠ IMPORTANT - This equipment is intended to be installed only by qualified personnel. The installation must be made in accordance with the current edition of the National Electrical Code and all applicable state and local building codes. The final installation must be approved by the appropriate, qualified electrical/building inspector(s). Improper installation may result in a fire or electrical hazard. Be sure the electrical power to the circuit has been disconnected before installing this electrical system.

⚠ IMPORTANT - Cet équipement est destiné à être installé uniquement par du personnel qualifié. L'installation doit être faite conformément à l'édition actuelle du Code national de l'électricité et à tous les codes de construction locaux et nationaux applicables. L'installation finale doit être approuvée par un ou plusieurs inspecteurs qualifiés en électricité / bâtiment. Une installation incorrecte peut entraîner un incendie ou un risque électrique. Assurez-vous que l'alimentation électrique du circuit a été déconnectée avant d'installer ce système électrique.

INSTALLATION INSTRUCTIONS:

INSTALLATION INSTRUCTIONS TO SINGLE CIRCUIT TRACK SYSTEMS:

1. Turn off power to track before beginning installation.
2. Align the adapter and contacts parallel with track.
3. Insert the adapter into the track and twist the adapter towards the polarity until the latch locks into track.

INSTALLATION INSTRUCTIONS TO TWO CIRCUIT TRACK SYSTEMS:

1. Turn off power to track before beginning installation.
2. Raise "Circuit Contact" on the mounting adapter by inserting the screwdriver under the contact and lifting upward.
3. Insert the adapter into the track and twist the adapter towards the polarity groove until the latch locks into track.

REMOVAL INSTRUCTIONS:

1. Turn off power to track before removing fixture.
2. Pull track adapter sleeve down and twist the adapter until latch unlocks.
3. Remove the fixture from track.

