# **LED Landscape Lighting — Mechanical Timer**









## WARNING

WARNING — THE INSTALLATION MUST BE CARRIED OUT BY A QUALIFIED ELECTRICIAN.

- 1. For indoor use only
- 2. DO NOT overload
- 3. Mechanical Timers are 125V 15 Amps 60Hz 1875W

## **CAUTION**

PLEASE READ INSTRUCTION BEFORE COMMENCING INSTALLATION AND RETAIN FOR FUTURE REFERENCES. Electrical products can cause death or injury, or damage to property. If in any doubt about the installation or use of this product, consult a competent electrician.

# **INSTALLATION GUIDE**

## **Operating Instructions**

#### 1. To set present time:

Turn the programming dial in the direction of the arrow until the triangular mark corresponds with the present time

# 2. To program:

Ensure the arrow is on the present time.

Push in the trippers situated around the dial to set equipment "ON" time.

Each tripper represents 30 minutes

#### 3. For example:

If you would like to set the time of activation from 11:00 AM to 1:30 PM, then push down the trippers situated between 11:00 AM and 1:30 PM, including the segments corresponding with 11:00 AM and 1:30 PM

#### 4. To activate equipment:

Having selected your program, plug in your equipment to the timer and then plug the timer into a 125V circuit. The timer will activate and deactivate the equipment as the dial rotates through the pushed down segment

5. The selected program will remain the same each day unless modified by the customer

