

INSTALLATION INSTRUCTIONS



WHAT'S IN THE BOX

- LED FIXTURE
- WIRE CONNECTORS

WHAT YOU'LL NEED

- SAFETY GLASSES
- SCREW DRIVER
- WIRE CUTTERS
- WIRING SUPPLIES AS SPECIFIED BY CODE

WARNING

- Turn off electrical power at fuse or circuit breaker box before wiring fixture to the power supply.
- Turn off the power when you perform any maintenance.
- Verify that supply voltage is correct by comparing it with the luminaire label information.
- For indoor use only.
- Modifications to the product voids the warranty.

For use with:

LED Flush Mount Fixture

FM-LP1615-3 | FM-LP1615-4

FM-LP1623-3 | FM-LP1623-4


IMPORTANT

Before assembling your PREMISE LED fixture, please make sure that you carefully read through this instruction sheet. Consider having your fixture installed by a qualified licensed electrician.

Note: The important safeguards and instructions that appear in this sheet are not meant to cover all possible conditions and situations that may occur. It must be understood that common sense, caution, and care are factors that cannot be built into any product. These factors must be supplied by the person(s) caring for and operating the fixture.

PREMISE LED Inc.
82-86 Carrier Drive
Toronto, ON Canada
M9W 5R1
PREMISELED.COM

FIXTURE DIAGRAM



- | | |
|------------------------|-----------------------|
| 1. Junction Box | 8. Black Fixture Wire |
| 2. Ground Screw | 9. LED Board |
| 3. Fixture Ground Wire | 10. Fixture Housing |
| 4. White Supply Wire | 11. LED Driver |
| 5. White Fixture Wire | 12. Cover Lens |
| 6. Black Supply Wire | 13. Fixture Screw |
| 7. Wire Connector | 14. Top Ring |

INSTALLING THE FIXTURE

PREMISE's FM Series Flush Mount fixture is designed to be installed via a ceiling junction box.

1. Turn off the power.
2. Remove the cover lens (12) from the fixture housing (10). Position your fixture over the junction box (1).
3. Pull the supply wires and ground wire out from the junction box (1).
4. Connect the ground wire to the junction box by ground screw (2). Connect the white supply wire (4) to the white fixture wire (5), connect the black supply wire (6) to the black fixture wire (8) by using wire connectors (7). Then, carefully tuck all wires back into the junction box (1).
5. Locate the fixture housing (10) over the junction box (1). Put the fixture screw through the long hole slot on the fixture housing (10) and thread into the junction box (1). Then secure the fixture housing (10) to the junction box (1) by tightening the two fixture screws (13).
6. Secure the cover lens (12) and the top ring to the fixture housing.

INSTRUCTIONS D'INSTALLATION



CONTENU DE LA BOÎTE

- LUMINAIRE LED
- CONNECTEURS DE FILS

CE DONT VOUS AUREZ BESOIN:

- LUNETTES DE PROTECTION
- TOURNEVIS
- COUPE-FIL
- FOURNITURE DE CÂBLAGE TEL QUE SPÉCIFIÉ PAR LES CODES ÉLECTRIQUES

AVERTISSEMENT

- Couper l'alimentation électrique au fusible ou à la boîte du disjoncteur avant de câbler le luminaire sur l'alimentation.
- Couper le courant électrique avant de faire la maintenance.
- Vérifier que la tension d'alimentation est correcte en la comparant avec les informations de l'étiquette du luminaire.
- Pour usage intérieur seulement
- Les modifications apportées au produit annulent la garantie.

Pour usage avec:

Plafonnier affleurant DEL

FM-LP1615-3 | FM-LP1615-4


FM-LP1623-3 | FM-LP1623-4

IMPORTANT

Avant d'assembler votre appareil, SVP de lire attentivement cette feuille d'instructions. Considérer d'embaucher un électricien agréé qualifié pour faire l'installation.

REMARQUE: Les garanties importantes et les instructions qui apparaissent dans ce manuel ne sont pas destinés à couvrir toutes les conditions et les situations possibles qui puissent se produire. Il faut comprendre que le bon sens, la prudence et les soins sont des facteurs qui ne peuvent pas être intégrés dans un produit quelconque. Ces facteurs doivent être fournis pas la (les) personne(s) en charge du soin et du fonctionnement de l'appareil.

DIAGRAMME DU LUMINAIRE



- | | |
|--|------------------------------|
| 1. Boîte de jonction | 8. Fil noir du luminaire |
| 2. Vis de mise à la terre | 9. Tableau LED |
| 3. Fil de mise à la terre du luminaire | 10. Boîtier du luminaire |
| 4. Fil blanc d'alimentation | 11. Conducteur LED |
| 5. Fil blanc du luminaire | 12. Lentille de recouvrement |
| 5. Fil noir d'alimentation | 13. Vis du luminaire |
| 7. Connecteur de fil | 14. Anneau supérieur |

INSTALLATION DU PLAFONNIER

Le plafonnier de la série FM de PREMISE est conçu pour être installé au plafond sur une boîte de jonction.

1. Couper le courant électrique.
2. Enlever la lentille de recouvrement (12) du boîtier du luminaire (10). Situer le luminaire sur la boîte de jonction (1).
3. Retirer les fils d'alimentation (6) et le fil de mise à la terre de la boîte de jonction (1).
4. Connecter le fil de mise à la terre à la boîte de jonction à l'aide de la vis de mise à la terre (2). Connecter le fil blanc d'alimentation (4) au fil blanc du luminaire (5). Connecter le fil noir d'alimentation (6) au fil noir du luminaire (8) à l'aide des connecteurs de fil (7). Ensuite placer avec précaution tous les fils dans la boîte de jonction (1).
5. Placer le boîtier du luminaire (10) au-dessus de la boîte de jonction (1). Mettre la vis du luminaire à travers la fente du long trou du boîtier du luminaire (10) et l'enfiler à la boîte de jonction (1). Puis, sécuriser le boîtier du luminaire (10) à la boîte de jonction (1) en serrant les 2 vis du luminaire (13).
6. Fixer la lentille de recouvrement (12) et l'anneau supérieur (14) sur le boîtier du luminaire.