

! SAFETY INFORMATION

Please read and understand this entire manual before attempting to assemble, install or operate the product.


WARNING

- RISK OF ELECTRIC SHOCK - Before beginning installation, turn off electricity at the circuit breaker box or the main fuse box.
- RISK OF FIRE - Use bulbs specified by the markings and/or labels on the fixture.

CAUTION

- For your safety, read instructions completely before beginning installation.
- If in doubt about electrical installation, consult a licensed electrician.
- Turn off electricity to fixture before replacing the bulb(s).

TOOLS REQUIRED




CARE AND MAINTENANCE


- Wipe clean using soft, dry cloth or static duster. Always avoid using harsh chemicals and abrasives to clean fixture as they may damage the finish.

If you need further assistance call Quozel Customer Care at 1-800-645-3184 (9:00am - 5:00pm EST), or visit us on-line at www.quozel.com.

PACKAGE CONTENTS



MOUNTING HARDWARE



1 Install Ceiling Canopy to Fixture Body

2 Install Glass Panels

Shorter Glass Panel "B"

Longer Glass Panel "A"

3 Install Crossbar Assembly

Outlet Box

4 Wiring

White wire from supply

White from fixture

Black (or red) wire from supply

Black from fixture

Ground wire from supply

Ground wire from fixture

Green ground screw

5 Install Ceiling Canopy to Crossbar Assembly

6 Install Bulbs

Install two correct bulbs referring to fixture markings and/or labels for maximum wattage.

Recommended Bulb Type (not included):

 BULB BASE TYPE Medium (E26)

 BULB TYPE TYPE A

Your installation is now complete! Restore electricity and save this sheet for future reference.