

SAFETY INFORMATION

Please read and understand this entire manual before attempting to assemble, install or operate the product.


WARNING

- RISK OF ELECTRIC SHOCK - Before beginning installation, turn off electricity at the circuit breaker box or the main fuse box.
- RISK OF FIRE - Use bulbs specified by the markings and/or labels on the fixture.

CAUTION

- For your safety, read instructions completely before beginning installation.
- If in doubt about electrical installation, consult a licensed electrician.
- Turn off electricity to fixture before replacing the bulb(s).

TOOLS REQUIRED




CARE AND MAINTENANCE


- Wipe clean using soft, dry cloth or static duster. Always avoid using harsh chemicals and abrasives to clean fixture as they may damage the finish.

If you need further assistance call Quoizel Customer Care at 1-800-645-3184 (9:00am - 5:00pm EST), or visit us on-line at www.quoizel.com.


PACKAGE CONTENTS



MOUNTING HARDWARE




AA Crossbar Assembly
x 1




BB Wire Connector
x 3



CC Outlet Box Screw
x 2



DD Ceiling Canopy
x 1



EE Quick Link
x 2





FF Fixture Chain
x 1




GG Allen Wrench
x 1

INSTALLATION


1 Install Center Rod and Fixture Loop




2 Install Side Arms and Decorative Ring





1. Place ring from over the fixture loop. Pass the top scroll of the side arm through the ring.



2. Trace the ring to the second scroll on the side arm.




3. Screw out the set screw on the holder underside of the socket cap with Allen wrench. Insert the bottom end of the side arm into the holder. Secure by threading the set screws back in the holder. Hand tighten until snug.



4. Attach the top end of the side arm to the center rod and secure with the lock screw. Hand tighten until snug.


3 Install Crossbar Assembly



4 Install Fixture Chain




Suggested chain length for Ceiling height:
 9 feet ceiling: use 7 links of chain and 2 quick links
 10 feet ceiling: use 17 links of chain and 2 quick links.
 11 feet ceiling: use 27 links of chain and 2 quick links.




5 Pull Supply Wires


Pull the supply wires with ground wire through the chain alternate links.



6 Wiring




7 Install Ceiling Canopy



* Ceiling Canopy shape is varies depends on item purchased.

8 Install Crystal Beads




INSTALLATION

9 Install Bulbs

Install five correct bulbs referring to fixture markings and/or labels for maximum wattage.

Recommended Bulb Type (not included):



Your installation is now complete! Restore electricity and save this sheet for future reference.