

Assembly Instruction Sheet #IS-ON2818 For Style ON2818WT and ON2818BN

Please go to www.quoizel.com for product cleaning tips. Go to the Care + Maintenance selection.

Tools Required: Flathead screwdriver, Phillips screwdriver, pliers, wire cutters, wire strippers, electrical tape, safety glasses.

Light Source: (4) Candelabra Base Bulbs 60W Maximum

Estimated Assembly Time: 30-45 minutes

Preparation: Identify and inspect all parts before beginning installation. Check package content list and diagrams below to be sure all parts are present. If any parts are missing or damaged, do not attempt to assemble, install, or operate the fixture. Contact customer service for replacement parts.


Note: This CONVERTIBLE fixture can be mounted as pendant light or semi-flush light. Refer to respective installation steps for installations.


△ Warnings and Cautions

Turn off electricity at circuit breaker or main fuse box before installation. Consult a licensed electrician if in doubt.

These instructions are provided for your safety. It is very important you read them completely before installing the fixture. We strongly recommend that a licensed, professional electrician perform the installation.

Disconnect fixture from power source before replacing bulbs. Make sure bulbs are given sufficient time to cool before removal. Do not subject glass parts to any shock while in operation or shattering may result.






STEP 3A - Install Crossbar Assembly

A. Pass the supply wires through the Crossbar Assembly (AA). Attach the Crossbar Assembly (AA) to the Outlet Box with the head of the Green Ground Screw facing you. Secure it with Outlet Box Screws (not included). Tighten until snug.


Outlet Box Screws (not included)

Figure 2A



STEP 4A – Fit Ceiling Canopy to Crossbar Assembly

A. Remove mounting balls from the Crossbar Assembly (AA). Fit the Ceiling Canopy (A) to the Crossbar Assembly (AA) and secure with mounting balls. Note: The Ceiling Canopy (A) should be snug against the ceiling and the mounting balls. If Not, adjust the length of the nipple on the Crossbar Assembly (AA) by



unscrewing the preassembled hex nut and lock washer and then screwing the mounting screws in or out of the crossbar until the correct length is achieved. Once the Ceiling Canopy (A) is secure, remove the mounting ball and Ceiling Canopy (A) and proceed to Step 5A.

STEP 2A - Assemble the Rods and the Ceiling Canopy

STEP 1A - Assemble Swivel and Ceiling

A. Thread the Nipple (F) onto the Swivel (D).

Washer (G) and the Lock Washer (H) over

the Nipple (F). Secure them with the Hex

B. Place the Ceiling Canopy (A), the Flat

Nut (E) and tighten until sung.

A. Determine the Rods (B/C) to be assembled to the Socket Assembly (J) according to your hanging height.

Figure 1A

B. Pass the supply wires and ground wire through the chosen rods (B/C) and the Ceiling Canopy (A). Thread the Socket Assembly (J), the chosen Rods (B/C) and the Ceiling Canopy (A) together. Hand tighten until snug.

Thank you for purchasing a Quoizel product. Need assistance with parts or assembly? Call Quoizel customer service at 1-631-273-2700 or visit us on-line at www.quoizel.com

November 2015

© 2015 Quoizel Inc.

Canopy together

STEP 5A - Wire Connections

A. Use standard wire connectors (not included) to make all wire connections. (Connectors are not included with fixture.) Twist connectors until wires are tightly joined together. Wrap each connection with approved electrical tape and carefully stuff all the connected wires into the Outlet Box.





Figure 5A

STEP 3B - Fit Ceiling Canopy to Crossbar Assembly

A. Remove mounting balls from the Crossbar Assembly (AA). Fit the Ceiling Canopy (A) to the Crossbar Assembly (AA) and secure with mounting balls. Note: The Ceiling Canopy (A) should be snug against the ceiling and the mounting balls. If Not, adjust the length of the nipple on the Crossbar Assembly (AA) by



Outlet Box


Supply Wires with

Ground Wire

unscrewing the preassembled hex nut and lock washer and then screwing the mounting screws in or out of the crossbar until the remove the mounting ball and Ceiling Canopy (A) and proceed to Step 4B.

STEP 6A - Install Fixture Body

A. Carefully tuck all wires into the outlet box and position the Ceiling Canopy (A) over the outlet box. Align the holes in the Ceiling Canopy (A) with the mounting screws, then attach the Ceiling Canopy (A) using the previously removed mounting balls. Hand tighten until snug.




STEP 7A - Install Crystal Bobeche and Bulb

Cover. B. This fixture uses candelabra bulb with standard screw


base. Maximum 60 watts. Insert bulb and screw snugly into place.

Your fixture is now assembled and ready to use. Enjoy!



Assembly Instructions for Semi-flush Light (Step 1B - Step 6B)

Part B, Part C and Part E will not be used in the assembly of the Semi-Flush Light fixture. Please set aside these parts.




STEP 1B - Install Ceiling Canopy to Socket Assembly

A. Pass supply wires with ground wire through the Nipple (F), the Ceiling Canopy (A), the Flat Washer (G), the Lock Washer (H) and the Hex Nut (E). Thread the Nipple (F) onto the Socket Assembly (J). Place the Ceiling Canopy (A), the Flat Washer (G) and the Lock Washer (H) over the Nipple (F). Secure with the Hex Nut (E) and hand tighten

until snug. Cut the wires leaving approximately 6" of wire extending from the Ceiling Canopy.

B. Optional Swivel: Install the Swivel to the Socket Assembly (J) and then attach the Nipple (F), the Ceiling Canopy (A), the Flat Washer (G) and Optional the Lock Washer (H) to the Swivel. Secure with the Hex Nut (E) and tighten until snug.




STEP 6B - Install Crystal

A. Attach the Crystal Bobeche (I) over the Candle Cover.

B. This fixture uses candelabra bulb with standard screw base. Maximum 60 watts. Insert bulb

Your fixture is now assembled and ready to use. Enjoy!



included). Tighten until snug.

Figure 2B

STEP 2B - Install Crossbar Assembly

Assembly (AA). Attach the Crossbar

A. Pass the supply wires through the Crossbar

Assembly (AA) to the Outlet Box with the

head of the Green Ground Screw facing

you. Secure it with Outlet Box Screws (not


correct length is achieved. Once the Ceiling Canopy (A) is secure,

Outlet Box Screws

(not included)

STEP 4B - Wire Connections

A. Use standard wire connectors (not included) to make all wire connections. (Connectors are not included with fixture.) Twist connectors until wires are tightly joined together. Wrap each connection with approved electrical tape and carefully stuff all the connected wires into the Outlet Box.



STEP 5B - Install Fixture Body

A. Carefully tuck all wires into the outlet box and position the Ceiling Canopy (A) over the outlet box. Align the holes in the Ceiling Canopy (A) with the mounting screws, then attach the Ceiling Canopy (A) using the previously removed mounting balls. Hand tighten until snug.




Figure 5B

Bobeche and Bulb


and screw snugly into place.


Thank you for purchasing a Quoizel product. Need assistance with parts or assembly? Call Quoizel customer service at 1-631-273-2700


November 2015

ON2818WT	ON2818BN		
FINISH: WESTERN BRONZE	FINISH: BRUSHED NICKEL		


PENDANT LIGHT








SEMI-FLUSH







	NO.	PART NUMBER	REPLACEMENT PART	QTY.	ITEM NUMBER
	1	9006EXBN	6"L ROD	2	ON2818BN
	2	9012EXBN	12"L ROD	2	
	1	9006EXWT	6"L ROD	2	ON2818WT
а	2	9012EXWT	12"L ROD	2	
	3	G12439CR	CRYSTAL BOBECHE	4	ON2818BN ON2818WT

NOTE: ALL DIMENSIONS ARE ROUNDED UP TO THE NEAREST 1/4 $^{\prime\prime}$

Thank you for purchasing a Quoizel product. Need assistance with parts or assembly? Call Quoizel customer service at 1-631-273-2700 or visit us on-line at www.quoizel.com

November2015

(Not Supplied)