



### Tools Required



### Light Source



### Fixture Height Adjustable 18" to 48"

#### ⚠ Warnings and Cautions

Turn off the electricity at the circuit breaker before installation. Consult a licensed electrician if in doubt about installation.











Turn off power to the fixture and allow the bulbs to cool before replacing.

### Package Contents

**Preparation:** Identify and inspect all parts before beginning the installation.


Missing or damaged parts? Contact your original place of purchase.

#### PARTS BAG




### Table of Contents

#### Crossbar Assembly




STEP 1

#### Downrod




STEP 2

#### Lanyard




STEP 3

#### Wiring



STEP 4

#### Ceiling Canopy




STEP 5

#### Bulb and Diffuser




STEP 6

## STEP 1





For angled ceilings,  
Swivel opening towards wall.

### 1 Step 1 Install crossbar assembly




### 2 Step 2 - 3 Test fitting ceiling canopy to mounting screws




## STEP 2

### Optional Rods


**8' ceiling:**  
(2) 6"L + (1) 12"L  
rods  
**9' ceiling:**  
(2) 6"L + (2) 12"L  
rods




1




2



3





### OPTION 1





### OPTION 2


## STEP 3



## STEP 4



**STEP 5**



**STEP 6**

