

**SAFETY INFORMATION**

Please read and understand this entire manual before attempting to assemble, install or operate the product.


**WARNING**

- RISK OF ELECTRIC SHOCK - Before beginning installation, turn off electricity at the circuit breaker box or the main fuse box.
- RISK OF FIRE - Use bulbs specified by the markings and/or labels on the fixture.

**CAUTION**

- For your safety, read instructions completely before beginning installation.
- If in doubt about electrical installation, consult a licensed electrician.
- Turn off electricity to fixture before replacing the bulb(s).

**TOOLS REQUIRED**




**CARE AND MAINTENANCE**


- Wipe clean using soft, dry cloth or static duster. Always avoid using harsh chemicals and abrasives to clean fixture as they may damage the finish.

If you need further assistance call Quoizel Customer Care at 1-800-645-3184(9:00am - 5:00pm EST), or visit us on-line at [www.quoizel.com](http://www.quoizel.com)

**PACKAGE CONTENTS**





**MOUNTING HARDWARE**




# INSTALLATION

## 1 Install Top Socket Assembly to Bottom Socket Assembly




Connect the male connector to the female connector first. Then tuck all slack wires into the center rod and install top socket assembly to bottom socket assembly.


## 2 Install Center Rod, Rod-With Nipple and Fixture Loop




## 3 Install Rings



## 4 Install Crossbar Assembly




## 5 Install Fixture Chain



**OPTIONAL:** Adjust Chain as desired, using pliers and soft cloth (neither included).


Suggested chain length for Ceiling height:  
8 feet ceiling: use 8 links of chain and 2 quick links  
9 feet ceiling: use 18 links of chain and 2 quick links  
10 feet ceiling: use 28 links of chain and 2 quick links.




# INSTALLATION

## 6 Pull Supply Wires

Pull the supply wires with ground wire through the chain alternate links.




## 7 Wiring



## 8 Install Ceiling Canopy

\* Ceiling Canopy shape is varies depends on item purchased.




## 9 Install Glass Shade and Bulbs

Install nine correct bulbs referring to fixture markings and/or labels for maximum wattage.

**Recommended Bulb Type (not included):**

  
BULB BASE TYPE  
Medium (E26)

  
100W  
MAX  
BULB TYPE  
TYPE A



Your installation is now complete! Restore electricity and save this sheet for future reference.