


Installation Instructions

ITEM NO. : TP240 TP241 TP242



1. Make sure Power is disconnected. Pass Bolt through keyhole slots in track and secure to Track Cable holder.
2. Pass the Canopy cable holder through Ceiling cover plate into Ceiling, and tighten with Toggle bolt.
3. Adjust cable length using Quick-release button.