

Item Number **4373900**

LED 12T8/48"/DIM/40 Direct Install

Specifications

- Energy Used (Watts): 12
- Brightness (Lumens): 1800
- Average Rated Hours: 50000
- Light Appearance (Kelvin): 4000
- Beam Spread: 220°
- CRI: 82
- Efficacy (LPW): 150
- Estimated Yearly Energy Cost**: \$1.45
- Package Type: Sleeve
- Approved for use in enclosed fixtures



Physical Characteristics

- Color Designation: Cool White
- Finish: Frost
- Housing Material: Glass
- Base: G13 (Medium BiPin)
- MOL: 48.00"
- MOD: 1.00"

Limited Warranty

5 Year

For full warranty information, please follow this link:

www.westinghouselighting.com/pdfs/warranty-cards/ESF-WH-COMMERCIAL.pdf



Warning

- Turn power off before inspection, installation, or removal.
- Risk of electric shock - Do not use where exposed to water or weather.
- Suitable for Damp Locations - The lamp is suitable for use in wet locations when used in an outdoor rated fixture.
- Do not open - no user serviceable parts inside.
- This device is not intended for use with emergency exit luminaires or emergency exit lights.
- This device complies with Part 15 of the FCC rules and has been tested and found to comply with the limits for a Class B digital device. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to the radio communication. Any changes or modifications not expressly approved by the manufacturer could avoid the user's authority to operate the equipment.
- This lamp may not be compatible with all dimmers.

Specifications are subject to change without notice, please visit www.westinghouselighting.com for latest information.

 and Westinghouse are trademarks of Westinghouse Electric Corporation. Used under license by Westinghouse Lighting. All Rights Reserved.

** Based on 3hrs./day 11¢/kWh - Cost depends on rates and use.

2021

Item Number **4373900**

Ballast LED Dimmer Compatibility

 Compatible
 NOT Compatible

Ballast Brand	Ballast Model #	Starting Method	# of Lamps Installed	Ballast Factor	Voltage	Status
ACT	ACT 2P32ISUNVE	INSTANT START	1	N	120/277	
ACT	ACT 2P32ISUNVE	INSTANT START	2	N	120/277	
ANTRON ELECTRONICS	A32T8MICLO	INSTANT START	1	L	120/277	
ANTRON ELECTRONICS	A32T8MICLO	INSTANT START	2	L	120/277	
ARCATA	ACT 3P32ISUNVLE	INSTANT START	2	L	120/277	
ARCATA	ACT 3P32ISUNVLE	INSTANT START	3	L	120/277	
DAMAR	EL232-120/277HF(1688B)	INSTANT START	1	N	120/277	
COOPER LIGHTING	CL-432ISUNV-R1-B	INSTANT START	3	H	120/277	
COOPER LIGHTING	CL-432ISUNV-R1-B	INSTANT START	4	H	120/277	
DAMAR	EL232-120/277HF(1688B)	INSTANT START	1	N	120/277	
DAMAR	EL232-120/277HF(1688B)	INSTANT START	2	N	120/277	
DAMAR	EL232HL-120/277HF(1688D)	INSTANT START	1	H	120/277	
DAMAR	EL232HL-120/277HF(1688D)	INSTANT START	2	H	120/277	
DAMAR	EL332-120/277HF(3654C)	INSTANT START	2	N	120/277	
DAMAR	EL332-120/277HF(3654C)	INSTANT START	3	N	120/277	
DAMAR	EL332HL-120/277HF(3654H)	INSTANT START	2	H	120/277	
DAMAR	EL332HL-120/277HF(3654H)	INSTANT START	3	H	120/277	
DAMAR	EL432-120/277HF(3093B)	INSTANT START	3	N	120/277	
DAMAR	EL432-120/277HF(3093B)	INSTANT START	4	N	120/277	
DAMAR	EL432HL-120/277HF(3093C)	INSTANT START	3	H	120/277	
DAMAR	EL432HL-120/277HF(3093C)	INSTANT START	4	H	120/277	
EIKO	PM-2x32T8-UNV-IS-H	INSTANT START	1	H	120/277	
EIKO	PM-2x32T8-UNV-IS-H	INSTANT START	2	H	120/277	
EIKO	PM-2X32T8-UNV-IS	INSTANT START	1	N	120/277	
EIKO	PM-2X32T8-UNV-IS	INSTANT START	2	N	120/277	
EIKO	PM-2X32T8-UNV-IS-L	INSTANT START	1	L	120/277	
EIKO	PM-2X32T8-UNV-IS-L	INSTANT START	2	L	120/277	
EIKO	PM-3X32T8-UNV-IS	INSTANT START	2	N	120/277	
EIKO	PM-3X32T8-UNV-IS	INSTANT START	3	N	120/277	
EIKO	PM-3X32T8-UNV-IS-H	INSTANT START	2	H	120/277	
EIKO	PM-3X32T8-UNV-IS-H	INSTANT START	3	H	120/277	
EIKO	PM-3X32T8-UNV-IS-L	INSTANT START	2	L	120/277	
EIKO	PM-3X32T8-UNV-IS-L	INSTANT START	3	L	120/277	
EIKO	PM-4X32T8-UNV-IS	INSTANT START	3	N	120/277	
EIKO	PM-4X32T8-UNV-IS	INSTANT START	4	N	120/277	
EIKO	PM-4X32T8-UNV-IS-L	INSTANT START	3	L	120/277	
EIKO	PM-4X32T8-UNV-IS-L	INSTANT START	4	L	120/277	
ESPEN	VE232MVHIPE	INSTANT START	1	N	120/277	
ESPEN	VE232MVHIPE	INSTANT START	2	N	120/277	
ESPEN	VE232MVHIPHE	INSTANT START	1	H	120/277	
ESPEN	VE232MVHIPHE	INSTANT START	2	H	120/277	
ESPEN	VE232MVHIPL	INSTANT START	1	L	120/277	
ESPEN	VE232MVHIPL	INSTANT START	2	L	120/277	
GENERAL ELECTRIC	332MAX-H-42T	INSTANT START	2	H	120/277	
GENERAL ELECTRIC	332MAX-H-42T	INSTANT START	3	H	120/277	
GENERAL ELECTRIC	332MAX-H-84TS	INSTANT START	2	H	120/277	
GENERAL ELECTRIC	332MAX-H-84TS	INSTANT START	3	H	120	
GENERAL ELECTRIC	332MAX-H-84TS	INSTANT START	3	H	277	
GENERAL ELECTRIC	GE132MAX-G-N	INSTANT START	1	N	120/277	

Compatible
NOT Compatible

Ballast Brand	Ballast Model #	Starting Method	# of Lamps Installed	Ballast Factor	Voltage	Status
GENERAL ELECTRIC	GEI32MAX-H/ULTRA	INSTANT START	1	H	120/277	
GENERAL ELECTRIC	GEI32MAX-L/ULTRA	INSTANT START	1	L	120/277	
GENERAL ELECTRIC	GEI32MAXP-N/ULTRA	INSTANT START	1	N	120/277	
GENERAL ELECTRIC	GE232MAX347-N	INSTANT START	1	N	347	
GENERAL ELECTRIC	GE232MAX347-N	INSTANT START	2	N	347	
GENERAL ELECTRIC	GE232MAX-G-N	INSTANT START	1	L	120/277	
GENERAL ELECTRIC	GE232MAX-G-N	INSTANT START	2	L	120/277	
GENERAL ELECTRIC	GE-232-MAX-H-42T	INSTANT START	1	H	120/277	
GENERAL ELECTRIC	GE-232-MAX-H-42T	INSTANT START	2	H	120/277	
GENERAL ELECTRIC	GE-232-MAX-H/ULTRA	INSTANT START	1	H	120/277	
GENERAL ELECTRIC	GE-232-MAX-H/ULTRA	INSTANT START	2	H	120/277	
GENERAL ELECTRIC	GE232MAX-L/ULTRA	INSTANT START	1	L	120/277	
GENERAL ELECTRIC	GE232MAX-L/ULTRA	INSTANT START	2	L	120/277	
GENERAL ELECTRIC	GE232MAX-N/ULTRA	INSTANT START	1	N	120/277	
GENERAL ELECTRIC	GE232MAX-N/ULTRA	INSTANT START	2	N	120/277	
GENERAL ELECTRIC	GE232MAXP90-V60	INSTANT START	1	H	120/277	
GENERAL ELECTRIC	GE232MAXP90-V60	INSTANT START	2	H	120/277	
GENERAL ELECTRIC	GE-232-MV-N	INSTANT START	1	N	120/277	
GENERAL ELECTRIC	GE-232-MV-N	INSTANT START	2	N	120/277	
GENERAL ELECTRIC	GE232MV-N-DIY	INSTANT START	1	N	120/277	
GENERAL ELECTRIC	GE232MV-N-DIY	INSTANT START	2	N	120/277	
GENERAL ELECTRIC	GE232-MVPS-N	PROGRAM START	1	N	120/277	
GENERAL ELECTRIC	GE232-MVPS-N	PROGRAM START	2	N	120/277	
GENERAL ELECTRIC	GE332MAX-G-N	INSTANT START	2	N	120/277	
GENERAL ELECTRIC	GE332MAX-G-N	INSTANT START	3	N	120/277	
GENERAL ELECTRIC	GE332MAX-L/ULTRA	INSTANT START	2	L	120/277	
GENERAL ELECTRIC	GE332MAX-L/ULTRA	INSTANT START	3	L	120/277	
GENERAL ELECTRIC	GE332MAX-N/ULTRA	INSTANT START	2	N	120/277	
GENERAL ELECTRIC	GE332MAX-N/ULTRA	INSTANT START	3	N	120/277	
GENERAL ELECTRIC	GE332MAXP90-V60	INSTANT START	2	H	120/277	
GENERAL ELECTRIC	GE332MAXP90-V60	INSTANT START	3	H	120/277	
GENERAL ELECTRIC	GE332MAXP-L/ULTRA	INSTANT START	2	L	120/277	
GENERAL ELECTRIC	GE332MAXP-L/ULTRA	INSTANT START	3	L	120/277	
GENERAL ELECTRIC	GE332MV-N	INSTANT START	2	N	120/277	
GENERAL ELECTRIC	GE332MV-N	INSTANT START	3	N	120/277	
GENERAL ELECTRIC	GE-332-MVPS-N	PROGRAM START	2	N	120/277	
GENERAL ELECTRIC	GE-332-MVPS-N	PROGRAM START	3	N	120/277	
GENERAL ELECTRIC	GE432-120-RES	INSTANT START	3	N	120	
GENERAL ELECTRIC	GE432-120-RES	INSTANT START	4	N	120	
GENERAL ELECTRIC	GE432MAX347-N	INSTANT START	3	N	347	
GENERAL ELECTRIC	GE432MAX347-N	INSTANT START	4	N	347	
GENERAL ELECTRIC	GE432MAX90-S60	INSTANT START	3	H	120/277	
GENERAL ELECTRIC	GE432MAX90-S60	INSTANT START	4	H	120/277	
GENERAL ELECTRIC	GE432MAX-G-H	INSTANT START	3	H	120/277	
GENERAL ELECTRIC	GE432MAX-G-H	INSTANT START	4	H	120/277	
GENERAL ELECTRIC	GE432MAX-G-N	INSTANT START	3	N	120/277	
GENERAL ELECTRIC	GE432MAX-G-N	INSTANT START	4	N	120/277	
GENERAL ELECTRIC	GE432MAX-H/ULTRA	INSTANT START	3	H	120/277	
GENERAL ELECTRIC	GE432MAX-H/ULTRA	INSTANT START	4	H	120/277	

Ballast Brand	Ballast Model #	Starting Method	# of Lamps Installed	Ballast Factor	Voltage	Status
GENERAL ELECTRIC	GE432MAX-L/ULTRA	INSTANT START	3	L	120/277	
GENERAL ELECTRIC	GE432MAX-L/ULTRA	INSTANT START	4	L	120/277	
GENERAL ELECTRIC	GE432MAX-H-42T	INSTANT START	3	H	120/277	
GENERAL ELECTRIC	GE432MAX-H-42T	INSTANT START	4	H	120/277	
GENERAL ELECTRIC	GE432MAX-N/ULTRA	INSTANT START	3	N	120/277	
GENERAL ELECTRIC	GE432MAX-N/ULTRA	INSTANT START	4	N	120/277	
GENERAL ELECTRIC	GE432MAXP90-S60	INSTANT START	3	H	120/277	
GENERAL ELECTRIC	GE432MAXP90-S60	INSTANT START	4	H	120/277	
GENERAL ELECTRIC	GE432MV-N-42T	INSTANT START	3	N	120/277	
GENERAL ELECTRIC	GE432MV-N-42T	INSTANT START	4	N	120/277	
HALCO	EP232IS/H/MV/HE	INSTANT START	1	H	120/277	
HALCO	EP232IS/H/MV/HE	INSTANT START	2	H	120/277	
HALCO	EP232IS/L/MV/HE	INSTANT START	1	L	120/277	
HALCO	EP232IS/L/MV/HE	INSTANT START	2	L	120/277	
HALCO	EP232IS/MV/HE	INSTANT START	1	N	120/277	
HALCO	EP232IS/MV/HE	INSTANT START	2	N	120/277	
HALCO	EP332IS/L/MV/HE	INSTANT START	2	L	120/277	
HALCO	EP332IS/L/MV/HE	INSTANT START	3	L	120/277	
HALCO	EP332IS/MV/HE	INSTANT START	2	N	120/277	
HALCO	EP332IS/MV/HE	INSTANT START	3	N	120/277	
HALCO	EP432IS/120/MC	INSTANT START	3	N	120/277	
HALCO	EP432IS/120/MC	INSTANT START	4	N	120/277	
HALCO	EP432IS/L/MV/HE	INSTANT START	3	L	120/277	
HALCO	EP432IS/L/MV/HE	INSTANT START	4	L	120/277	
HALCO	EP432IS/MV/HE	INSTANT START	3	N	120/277	
HALCO	EP432IS/MV/HE	INSTANT START	4	N	120/277	
HATCH	HL232BIS/UV/HE/W	INSTANT START	1	N	120/277	
HATCH	HL232BIS/UV/HE/W	INSTANT START	2	N	120/277	
HATCH	HL432BIS/UV/HE/W	INSTANT START	3	N	120/277	
HATCH	HL432BIS/UV/HE/W	INSTANT START	4	N	120/277	
HOWARD INDUSTRIES	E2/32IS-120MC	INSTANT START	1	N	120	
HOWARD INDUSTRIES	E2/32IS-120MC	INSTANT START	2	N	120	
HOWARD INDUSTRIES	EP2/32IS/MV/MC/HE	INSTANT START	1	N	120/277	
HOWARD INDUSTRIES	EP2/32IS/MV/MC/HE	INSTANT START	2	N	120/277	
HOWARD INDUSTRIES	EP3/32IS/MV/MC/HE	INSTANT START	2	N	120/277	
HOWARD INDUSTRIES	EP3/32IS/MV/MC/HE	INSTANT START	3	N	120/277	
HOWARD INDUSTRIES	EP3/32IS/MV/SC/HE	INSTANT START	2	N	120/277	
HOWARD INDUSTRIES	EP3/32IS/MV/SC/HE	INSTANT START	3	N	120/277	
HOWARD INDUSTRIES	EP4/32IS/MV/MC/HE	INSTANT START	3	N	120/277	
HOWARD INDUSTRIES	EP4/32IS/MV/MC/HE	INSTANT START	4	N	120/277	
HOWARD INDUSTRIES	EPH2/32IS/MV/MC/HE	INSTANT START	1	H	120/277	
HOWARD INDUSTRIES	EPH2/32IS/MV/MC/HE	INSTANT START	2	H	120/277	
HOWARD INDUSTRIES	EPH3/32IS/MV/MC/HE	INSTANT START	2	N	120/277	
HOWARD INDUSTRIES	EPH3/32IS/MV/MC/HE	INSTANT START	3	N	120/277	
HOWARD INDUSTRIES	EPH4/32IS/MV/SC/HE	INSTANT START	3	H	120/277	
HOWARD INDUSTRIES	EPH4/32IS/MV/SC/HE	INSTANT START	4	H	120/277	
HOWARD INDUSTRIES	EPL2/32IS/MV/MC/HE	INSTANT START	1	L	120/277	
HOWARD INDUSTRIES	EPL2/32IS/MV/MC/HE	INSTANT START	2	L	120/277	

Ballast Brand	Ballast Model #	Starting Method	# of Lamps Installed	Ballast Factor	Voltage	Status
HOWARD INDUSTRIES	EPL3/32IS/MV/SC/HE	INSTANT START	2	L	120/277	
HOWARD INDUSTRIES	EPL3/32IS/MV/SC/HE	INSTANT START	3	L	120/277	
HOWARD INDUSTRIES	EPL4/32IS/MV/MC/HE	INSTANT START	3	L	120/277	
HOWARD INDUSTRIES	EPL4/32IS/MV/MC/HE	INSTANT START	4	L	120/277	
KEystone	KTEB-232LBF-1-TP-PIC-EV	INSTANT START	1	N	120	
KEystone	KTEB-232LBF-1-TP-PIC-EV	INSTANT START	2	N	120	
KEystone	KTEB-232-UV-IS-H-P	INSTANT START	1	H	120/277	
KEystone	KTEB-232-UV-IS-H-P	INSTANT START	2	H	120/277	
KEystone	KTEB-232-UV-IS-N-P	INSTANT START	1	N	120/277	
KEystone	KTEB-232-UV-IS-N-P	INSTANT START	2	N	120	
KEystone	KTEB-232-UV-IS-N-P	NSTANT START	2	N	277	
KEystone	KTEB-332-UV-IS-H-P	INSTANT START	2	H	120/277	
KEystone	KTEB-332-UV-IS-H-P	INSTANT START	3	H	120/277	
KEystone	KTEB-332-UV-IS-N-P	INSTANT START	2	N	120/277	
KEystone	KTEB-332-UV-IS-N-P	INSTANT START	3	N	120/277	
KEystone	KTEB-432RIS-1-TP-SL	INSTANT START	3	N	120	
KEystone	KTEB-432RIS-1-TP-SL	INSTANT START	4	N	120	
KEystone	KTEB-432-UV-IS-H-P	INSTANT START	3	H	120/277	
KEystone	KTEB-432-UV-IS-H-P	INSTANT START	4	H	120/277	
KEystone	KTEB-432-UV-IS-N-P	INSTANT START	3	N	120/277	
KEystone	KTEB-432-UV-IS-N-P	INSTANT START	4	N	120/277	
LIGHTING PRODUCTS LIMITED	EB-332EBF-UV-TP-HE	INSTANT START	2	L	120/277	
LIGHTING PRODUCTS LIMITED	EB-332EBF-UV-TP-HE	INSTANT START	3	L	120/277	
MAXLITE	MLEU322HEL/SC	INSTANT START	1	N	120/277	
MAXLITE	MLEU322HEL/SC	INSTANT START	2	N	120/277	
MAXLITE	MLEU323H/SC	INSTANT START	2	H	120/277	
MAXLITE	MLEU323H/SC	INSTANT START	3	H	120/277	
MAXLITE	MLEU324HE/SC	INSTANT START	3	N	120/277	
MAXLITE	MLEU324HE/SC	INSTANT START	4	N	120/277	
MAXLITE	SKEU322HEL/SC	INSTANT START	1	L	120/277	
MAXLITE	SKEU322HEL/SC	INSTANT START	2	L	120/277	
MAXLITE	SKEU323L/SC	INSTANT START	2	L	120/277	
MAXLITE	SKEU323L/SC	INSTANT START	3	L	120/277	
MAXLITE	SKEU324HE/SC	INSTANT START	3	N	120/277	
MAXLITE	SKEU324HE/SC	INSTANT START	4	N	120/277	
OSRAM SYLVANIA	QHE 1X32T8/UNV ISH-SC	INSTANT START	1	H	120/277	
OSRAM SYLVANIA	QHE 1X32T8/UNV ISL-SC	INSTANT START	1	L	120/277	
OSRAM SYLVANIA	QHE 1X32T8/UNV ISN-SC	INSTANT START	1	N	120/277	
OSRAM SYLVANIA	QHE 2X32T8/UNV ISH HT-SC	INSTANT START	1	H	120/277	
OSRAM SYLVANIA	QHE 2X32T8/UNV ISH HT-SC	INSTANT START	2	H	120/277	
OSRAM SYLVANIA	QHE 2X32T8/UNV ISH-SC	INSTANT START	1	H	120/277	
OSRAM SYLVANIA	QHE 2X32T8/UNV ISH-SC	INSTANT START	2	H	120/277	
OSRAM SYLVANIA	QHE 2X32T8/UNV ISL-SC	INSTANT START	1	L	120/277	
OSRAM SYLVANIA	QHE 2X32T8/UNV ISL-SC	INSTANT START	2	L	120/277	
OSRAM SYLVANIA	QHE 2X32T8/UNV ISN-SC	INSTANT START	1	N	120/277	
OSRAM SYLVANIA	QHE 2X32T8/UNV ISN-SC	INSTANT START	2	N	120/277	
OSRAM SYLVANIA	QHE 2X32T8/UNV PSN-MC	PROGRAM RAPID START	1	H	120/277	
OSRAM SYLVANIA	QHE 2X32T8/UNV PSN-MC	PROGRAM RAPID START	2	H	120/277	
OSRAM SYLVANIA	QHE 3X32T8/UNV ISH-HT-SC	INSTANT START	2	H	120/277	

Ballast Brand	Ballast Model #	Starting Method	# of Lamps Installed	Ballast Factor	Voltage	Status
OSRAM SYLVANIA	QHE 3X32T8/UNV ISH-HT-SC	INSTANT START	3	H	120/277	
OSRAM SYLVANIA	QHE 3X32T8/UNV ISL-SC	INSTANT START	2	L	120/277	
OSRAM SYLVANIA	QHE 3X32T8/UNV ISL-SC	INSTANT START	3	L	120/277	
OSRAM SYLVANIA	QHE 3X32T8/UNV ISN-SC	INSTANT START	2	N	120/277	
OSRAM SYLVANIA	QHE 3X32T8/UNV ISN-SC	INSTANT START	3	N	120/277	
OSRAM SYLVANIA	QHE 3X32T8/UNV PSN-SC	PROGRAM RAPID START	2	N	120/277	
OSRAM SYLVANIA	QHE 3X32T8/UNV PSN-SC	PROGRAM RAPID START	3	N	120/277	
OSRAM SYLVANIA	QHE 4x32T8/UNV ISH-SC	INSTANT START	3	H	120/277	
OSRAM SYLVANIA	QHE 4x32T8/UNV ISH-SC	INSTANT START	4	H	120/277	
OSRAM SYLVANIA	QHE 4X32T8/UNV ISL-SC	INSTANT START	3	L	120/277	
OSRAM SYLVANIA	QHE 4X32T8/UNV ISL-SC	INSTANT START	4	L	120/277	
OSRAM SYLVANIA	QHE 4X32T8/UNV ISN-SC	INSTANT START	3	N	120/277	
OSRAM SYLVANIA	QHE 4X32T8/UNV ISN-SC	INSTANT START	4	N	120/277	
OSRAM SYLVANIA	QHE 4X32T8/UNV PSN-SC	PROGRAM RAPID START	3	N	120/277	
OSRAM SYLVANIA	QHE 4X32T8/UNV PSN-SC	PROGRAM RAPID START	4	N	120/277	
OSRAM SYLVANIA	QT 2X32/347 ISH-SC	INSTANT START	1	H	347	
OSRAM SYLVANIA	QT 2X32/347 ISH-SC	INSTANT START	2	H	347	
OSRAM SYLVANIA	QT 3x32/277 IS	INSTANT START	2	N	120/277	
OSRAM SYLVANIA	QT 3x32/277 IS	INSTANT START	3	N	120/277	
OSRAM SYLVANIA	QTP 2X32T8/UNV ISL-SC	INSTANT START	1	L	120/277	
OSRAM SYLVANIA	QTP 2X32T8/UNV ISL-SC	INSTANT START	2	L	120/277	
OSRAM SYLVANIA	QTP 2X32T8/UNV ISN-SC	INSTANT START	1	N	120/277	
OSRAM SYLVANIA	QTP 2X32T8/UNV ISN-SC	INSTANT START	2	N	120/277	
OSRAM SYLVANIA	QTP 3X32T8/UNV ISN-SC	INSTANT START	2	N	120/277	
OSRAM SYLVANIA	QTP 3X32T8/UNV ISN-SC	INSTANT START	3	N	120/277	
OSRAM SYLVANIA	QTP2x32T8/277 ISN-D	INSTANT START	1	L	277	
OSRAM SYLVANIA	QTP2x32T8/277 ISN-D	INSTANT START	2	L	277	
PACIFIC FLUORESCENT	EB-232IS-120-RES	INSTANT START	1	N	120	
PACIFIC FLUORESCENT	EB-232IS-120-RES	INSTANT START	2	N	120	
PHILIPS-ADVANCE	ICN-132-MC	INSTANT START	1	N	120/277	
PHILIPS-ADVANCE	ICN-1P32-N	INSTANT START	1	N	120/277	
PHILIPS-ADVANCE	ICN-2P32-N	INSTANT START	1	N	120/277	
PHILIPS-ADVANCE	ICN-2P32-N	INSTANT START	2	N	120/277	
PHILIPS-ADVANCE	ICN-3P32-N	INSTANT START	2	N	120/277	
PHILIPS-ADVANCE	ICN-3P32-N	INSTANT START	3	N	120/277	
PHILIPS-ADVANCE	ICN-3P32-SC	INSTANT START	2	N	120/277	
PHILIPS-ADVANCE	ICN-3P32-SC	INSTANT START	3	N	120/277	
PHILIPS-ADVANCE	ICN-4P32-N	INSTANT START	3	N	120/277	
PHILIPS-ADVANCE	ICN-4P32-N	INSTANT START	4	N	120/277	
PHILIPS-ADVANCE	IOP-1P32-N	INSTANT START	1	N	120/277	
PHILIPS-ADVANCE	IOP-2P32HL-SC	INSTANT START	1	H	120/277	
PHILIPS-ADVANCE	IOP-2P32HL-SC	INSTANT START	2	H	120/277	
PHILIPS-ADVANCE	IOP-2P32-LW-N	INSTANT START	1	L	120/277	
PHILIPS-ADVANCE	IOP-2P32-LW-N	INSTANT START	2	L	120/277	
PHILIPS-ADVANCE	IOP-2P32-N	INSTANT START	1	N	120/277	
PHILIPS-ADVANCE	IOP-2P32-N	INSTANT START	2	N	120/277	
PHILIPS-ADVANCE	IOP-3P32HL-90C-SC	INSTANT START	2	H	120/277	
PHILIPS-ADVANCE	IOP-3P32HL-90C-SC	INSTANT START	3	H	120/277	
PHILIPS-ADVANCE	IOP-3P32-N	INSTANT START	2	N	120/277	

 Compatible
 NOT Compatible

Ballast Brand	Ballast Model #	Starting Method	# of Lamps Installed	Ballast Factor	Voltage	Status
PHILIPS-ADVANCE	IOP-3P32-N	INSTANT START	3	N	120/277	
PHILIPS-ADVANCE	IOP-3PSP32-SC	PROGRAM START	2	N	120/277	
PHILIPS-ADVANCE	IOP-3PSP32-SC	PROGRAM START	3	N	120/277	
PHILIPS-ADVANCE	IOP-4P32-HL-SC	INSTANT START	3	H	120/277	
PHILIPS-ADVANCE	IOP-4P32-HL-SC	INSTANT START	4	H	120/277	
PHILIPS-ADVANCE	IOP-4P32-LW-N	INSTANT START	3	L	120/277	
PHILIPS-ADVANCE	IOP-4P32-LW-N	INSTANT START	4	L	120/277	
PHILIPS-ADVANCE	IOP-4P32-N	INSTANT START	3	N	120/277	
PHILIPS-ADVANCE	IOP-4P32-N	INSTANT START	4	N	120/277	
PHILIPS-ADVANCE	IOP-4P32-SC	INSTANT START	3	N	120/277	
PHILIPS-ADVANCE	IOP-4P32-SC	INSTANT START	4	N	120/277	
PHILIPS-ADVANCE	IOP-4PSP32-LW-SC	PROGRAM START	3	L	120/277	
PHILIPS-ADVANCE	IOP-4PSP32-LW-SC	PROGRAM START	4	L	120/277	
PHILIPS-ADVANCE	IOP-4PSP32-SC	PROGRAM START	3	N	120/277	
PHILIPS-ADVANCE	IOP-4PSP32-SC	PROGRAM START	4	N	120/277	
PHILIPS-ADVANCE	IOPA-1P32-N	INSTANT START	1	N	120/277	
PHILIPS-ADVANCE	IOPA-2P32-HL-N	INSTANT START	1	H	120/277	
PHILIPS-ADVANCE	IOPA-2P32-HL-N	INSTANT START	2	H	120/277	
PHILIPS-ADVANCE	IOPA-3P32-LW-N	INSTANT START	2	L	120/277	
PHILIPS-ADVANCE	IOPA-3P32-LW-N	INSTANT START	3	L	120/277	
PHILIPS-ADVANCE	IOPA-3P32-N	INSTANT START	2	N	120/277	
PHILIPS-ADVANCE	IOPA-3P32-N	INSTANT START	3	N	120/277	
PHILIPS-ADVANCE	IOPA-4P32-HL	INSTANT START	3	H	120/277	
PHILIPS-ADVANCE	IOPA-4P32-HL	INSTANT START	4	H	120/277	
PHILIPS-ADVANCE	IOPA-4P32-HL-SC	INSTANT START	3	H	120/277	
PHILIPS-ADVANCE	IOPA-4P32-HL-SC	INSTANT START	4	H	120/277	
PHILIPS-ADVANCE	IOPA-4P32-N	INSTANT START	3	N	120/277	
PHILIPS-ADVANCE	IOPA-4P32-N	INSTANT START	4	N	120/277	
PHILIPS-ADVANCE	IOPA-4P32-SC	INSTANT START	3	N	120/277	
PHILIPS-ADVANCE	IOPA-4P32-SC	INSTANT START	4	N	120/277	
PHILIPS-ADVANCE	REB-4P32-SC	INSTANT START	3	N	120	
PHILIPS-ADVANCE	REB-4P32-SC	INSTANT START	4	N	120	
PHILIPS-ADVANCE	VEL-2P32-SC	INSTANT START	1	N	277	
PHILIPS-ADVANCE	VEL-2P32-SC	INSTANT START	2	N	277	
PHILIPS-ADVANCE	VEL-3P32-SC	INSTANT START	2	N	120/277	
PHILIPS-ADVANCE	VEL-3P32-SC	INSTANT START	3	N	120/277	
PLUSRITE	BAF232IS/MV	INSTANT START	1	N	120/277	
PLUSRITE	BAF232IS/MV	INSTANT START	2	N	120/277	
PLUSRITE	BAF332IS/MV	INSTANT START	2	N	120/277	
PLUSRITE	BAF332IS/MV	INSTANT START	3	N	120/277	
PLUSRITE	BAF332IS/MV/L	INSTANT START	2	L	120/277	
PLUSRITE	BAF332IS/MV/L	INSTANT START	3	L	120/277	
PLUSRITE	BAF432IS/MV	INSTANT START	3	N	120/277	
PLUSRITE	BAF432IS/MV	INSTANT START	4	N	120/277	
PLUSRITE	BAF432IS/MV/L	INSTANT START	3	L	120/277	
PLUSRITE	BAF432IS/MV/L	INSTANT START	4	L	120/277	
PROLUME	EP232IS/L/MV/SL	INSTANT START	1	L	120/277	
PROLUME	EP232IS/L/MV/SL	INSTANT START	2	L	120/277	
PROLUME	E432IS/120/R/SL	INSTANT START	3	N	120	



Compatible
NOT Compatible

Ballast Brand	Ballast Model #	Starting Method	# of Lamps Installed	Ballast Factor	Voltage	Status
PROLUME	E432IS/120/R/SL	INSTANT START	4	N	120	Compatible
SOLA	E-758-U-232-MC	INSTANT START	1	N	120/277	Compatible
SOLA	E-758-U-232-MC	INSTANT START	2	N	120/277	Compatible
SUNPARK	120-1/32IS HPF	INSTANT START	1	N	120	Compatible
SUNPARK	120-3/32IS MPF	INSTANT START	2	N	120	Compatible
SUNPARK	120-3/32IS MPF	INSTANT START	3	N	120	Compatible
SUNPARK	SL15T	PROGRAM START	1	N	120	NOT Compatible
SUNPARK	SL15T	PROGRAM START	2	N	120	NOT Compatible
SUNPARK	U-2/32ISE-LBF	INSTANT START	1	L	120/277	Compatible
SUNPARK	U-2/32ISE-LBF	INSTANT START	2	L	120/277	Compatible
SUNPARK	U-3/32ISE	INSTANT START	2	N	120/277	Compatible
SUNPARK	U-3/32ISE	INSTANT START	3	N	120/277	Compatible
SUNPARK	U-3/32ISE-HBF	INSTANT START	2	H	120/277	Compatible
SUNPARK	U-3/32ISE-HBF	INSTANT START	3	H	120/277	Compatible
SUNPARK	U-4/32IS HBF	INSTANT START	3	H	120/277	Compatible
SUNPARK	U-4/32IS HBF	INSTANT START	4	H	120/277	Compatible
SUNPARK	U-4/32IS HP,F	INSTANT START	3	N	120/277	Compatible
SUNPARK	U-4/32IS HP,F	INSTANT START	4	N	120/277	Compatible
SUNPARK	U-4/32ISE-LBF	INSTANT START	3	L	120/277	Compatible
SUNPARK	U-4/32ISE-LBF	INSTANT START	4	L	120/277	Compatible
SUPERIOR LIFE	70201	INSTANT START	1	N	120/277	NOT Compatible
SUPERIOR LIFE	70201	INSTANT START	2	N	120/277	Compatible
TCP	E3P32ISUNVE	INSTANT START	2	H	120/277	Compatible
TCP	E3P32ISUNVE	INSTANT START	3	H	120/277	Compatible
TCP	E3P32ISUNVHE	INSTANT START	2	N	120/277	NOT Compatible
TCP	E3P32ISUNVHE	INSTANT START	3	N	120/277	NOT Compatible
TCP	E3P32ISUNVLE	INSTANT START	2	L	120/277	NOT Compatible
TCP	E3P32ISUNVLE	INSTANT START	3	L	120/277	Compatible
TCP	E4P32ISUNVE	INSTANT START	3	N	120/277	Compatible
TCP	E4P32ISUNVE	INSTANT START	4	N	120/277	Compatible
TCP	E4P32ISUNVHE	INSTANT START	3	N	120/277	Compatible
TCP	E4P32ISUNVHE	INSTANT START	4	N	120/277	Compatible
TCP	E4P32ISUNVLE	INSTANT START	3	L	120/277	NOT Compatible
TCP	E4P32ISUNVLE	INSTANT START	4	L	120/277	NOT Compatible
TCP	TCP3P32ISUNVH	INSTANT START	2	H	120/277	NOT Compatible
TCP	TCP3P32ISUNVH	INSTANT START	3	H	120/277	NOT Compatible
TOPAZ	B232IUNVHEH/A-TPZ	INSTANT START	1	H	120/277	Compatible
TOPAZ	B232IUNVHEH/A-TPZ	INSTANT START	2	H	120/277	Compatible
TOPAZ	B432IUNVHEH/A-TPZ	INSTANT START	3	H	120/277	Compatible
TOPAZ	B432IUNVHEH/A-TPZ	INSTANT START	4	H	120/277	Compatible
UNIVERSAL LIGHTING TECHNOLOGIES	B132IUNVHP-N	INSTANT START	1	N	120/277	Compatible
UNIVERSAL LIGHTING TECHNOLOGIES	B232I120RES-A	INSTANT START	1	N	120	Compatible
UNIVERSAL LIGHTING TECHNOLOGIES	B232I120RES-A	INSTANT START	2	N	120	Compatible
UNIVERSAL LIGHTING TECHNOLOGIES	B232I277RH-A	INSTANT START	1	H	277	Compatible
UNIVERSAL LIGHTING TECHNOLOGIES	B232I277RH-A	INSTANT START	2	H	277	Compatible
UNIVERSAL LIGHTING TECHNOLOGIES	B232IUNV-C	INSTANT START	1	N	120/277	Compatible
UNIVERSAL LIGHTING TECHNOLOGIES	B232IUNV-C	INSTANT START	2	N	120/277	Compatible
UNIVERSAL LIGHTING TECHNOLOGIES	B232IUNVEL-A	INSTANT START	1	L	120/277	Compatible
UNIVERSAL LIGHTING TECHNOLOGIES	B232IUNVEL-A	INSTANT START	2	L	120/277	Compatible

Ballast Brand	Ballast Model #	Starting Method	# of Lamps Installed	Ballast Factor	Voltage	Status
UNIVERSAL LIGHTING TECHNOLOGIES	B232IUNVHEH-A	INSTANT START	1	N	120/277	
UNIVERSAL LIGHTING TECHNOLOGIES	B232IUNVHEH-A	INSTANT START	2	N	120/277	
UNIVERSAL LIGHTING TECHNOLOGIES	B232IUNVHP-B	INSTANT START	1	N	120/277	
UNIVERSAL LIGHTING TECHNOLOGIES	B232IUNVHP-B	INSTANT START	2	N	120/277	
UNIVERSAL LIGHTING TECHNOLOGIES	B232IUNVHP-N	INSTANT START	1	N	120/277	
UNIVERSAL LIGHTING TECHNOLOGIES	B232IUNVHP-N	INSTANT START	2	N	120/277	
UNIVERSAL LIGHTING TECHNOLOGIES	B232PUNVHE-B	PROGRAM START	1	N	120/277	
UNIVERSAL LIGHTING TECHNOLOGIES	B232PUNVHE-B	PROGRAM START	2	N	120/277	
UNIVERSAL LIGHTING TECHNOLOGIES	B233IUNVHE-A	INSTANT START	1	N	120/277	
UNIVERSAL LIGHTING TECHNOLOGIES	B233IUNVHE-A	INSTANT START	2	N	120/277	
UNIVERSAL LIGHTING TECHNOLOGIES	B332IHRVBH-E	INSTANT START	2	H	120/277	
UNIVERSAL LIGHTING TECHNOLOGIES	B332IHRVBH-E	INSTANT START	3	H	120/277	
UNIVERSAL LIGHTING TECHNOLOGIES	B332IUNVHP-A	INSTANT START	2	N	120/277	
UNIVERSAL LIGHTING TECHNOLOGIES	B332IUNVHP-A	INSTANT START	3	N	120/277	
UNIVERSAL LIGHTING TECHNOLOGIES	B432IUNVHE-A	INSTANT START	3	N	120/277	
UNIVERSAL LIGHTING TECHNOLOGIES	B432IUNVHE-A	INSTANT START	4	N	120/277	
UNIVERSAL LIGHTING TECHNOLOGIES	B432IUNVHEH-E	INSTANT START	3	H	120/277	
UNIVERSAL LIGHTING TECHNOLOGIES	B432IUNVHEH-E	INSTANT START	4	H	120/277	
UNIVERSAL LIGHTING TECHNOLOGIES	B432IUNVHE L-A	INSTANT START	3	L	120/277	
UNIVERSAL LIGHTING TECHNOLOGIES	B432IUNVHE L-A	INSTANT START	4	L	120/277	
UNIVERSAL LIGHTING TECHNOLOGIES	B432IUNVHP-A	INSTANT START	3	N	120/277	
UNIVERSAL LIGHTING TECHNOLOGIES	B432IUNVHP-A	INSTANT START	4	N	120/277	
UNIVERSAL LIGHTING TECHNOLOGIES	B432PUNVHE-A	PROGRAM START	3	N	120/277	
UNIVERSAL LIGHTING TECHNOLOGIES	B432PUNVHE-A	PROGRAM START	4	N	120/277	
WATRAM	DB-232N-MV-TP-HE	INSTANT START	1	N	120/277	
WATRAM	DB-232N-MV-TP-HE	INSTANT START	2	N	120/277	
WATRAM	DB-232N-MV-TP-HE (SC)	INSTANT START	1	N	120/277	
WATRAM	DB-232N-MV-TP-HE (SC)	INSTANT START	2	N	120/277	
WATRAM	DB-332N-MV-TP-HE	INSTANT START	2	N	120/277	
WATRAM	DB-332N-MV-TP-HE	INSTANT START	3	N	120/277	
WATRAM	DB-432L-MV-TP-HE	INSTANT START	3	L	120/277	
WATRAM	DB-432L-MV-TP-HE	INSTANT START	4	L	120/277	
WATRAM	DB-432N-MV-TP-HE	INSTANT START	3	N	120/277	
WATRAM	DB-432N-MV-TP-HE	INSTANT START	4	N	120/277	
WATRAM	DBG32N-MV-TP-PS-HL	PROGRAM START	2	H	120/277	
WATRAM	DBG32N-MV-TP-PS-HL	PROGRAM START	3	H	120/277	
WORK HORSE	WHS3G3-UNV-T8-IS	INSTANT START	2	N	120/277	
WORK HORSE	WHS3G3-UNV-T8-IS	INSTANT START	3	N	120/277	
WORK HORSE	WHS3G4-UNV-T8-IS	INSTANT START	3	N	120/277	
WORK HORSE	WHS3G4-UNV-T8-IS	INSTANT START	4	N	120/277	

Emergency Ballast

 Compatible
 **NOT** Compatible

Ballast Brand	Ballast Model #	Starting Method	# of Lamps	Status
BODINE	B100	DC	1	
CONTRACTOR SELECT	E1500	DC	1	
ESPEN	VEM500DV(L)	AC	1	
ESPEN	VEM700DV(L)	AC	1	
EXITRONIX	XEB-7-B-LM	AC	1	
KEYSTONE	KT-EMRG-500	DC	1	
KEYSTONE	KT-EMRG-1300-T5	AC	1	
KEYSTONE	KT-EMRG-1400	DC	1	
TAMLITE	BAL500LPACTD	AC	1	
TAMLITE	BAL1400LPACTD	AC	1	
TAMLITE	PAC0005	DC	1	

WESTINGHOUSE LIGHTING

Specifications are subject to change without notice, please visit www.westinghouselighting.com for latest information.

 and Westinghouse are trademarks of Westinghouse Electric Corporation.
 Used under license by Westinghouse Lighting. All Rights Reserved.