

BEFORE YOU START:

- · Please check local electrical codes before beginning
- Turn power off before installing
- · Make sure to use proper rated wire

PLUG IN INSTALLATION (Skip this step if you are using HARDWIRE INSTALLATION:

- 1. Layout where fixture(s) are to be placed, insuring that first fixture is mounted within 6 feet of an outlet. Remove plastic receptacle cap that covers the INPUT socket where you will plug in power cord. (FIG. 1)
- 2. Plug-in power cord to the INPUT socket. Do not force, it should plug-in easily. (FIG. 2)
- 3. Mount fixture to under cabinet or where you plan to locate fixture. Plug power cord into wall outlet. (FIG. 3).
- 4. Connect multiple fixtures using optional flexible fixture to fixture connectors. Do not exceed max. of 200W per run.
- 5. Adjust white color (Kelvin) levels.




FIG. 5

Supply Wires

▼Flex Conduit

TOOLS NEEDED:

HARDWIRE INSTALLATION:

- 1. Open up wireway cut-out and wiring compartment (there are screws located on each side of fixture) (FIG. 4) and pull out 3 modular wire connectors (black, white and green). Modular (push-in) connectors are suitable for #12-14 AWG solid core wire. Strip back jacket on AC supply wires 3/8" and use modular (push-in) connector to connect wires (BLACK to BLACK, WHITE to WHITE, GREEN to GREEN). WARNING: DO NOT MIX WIRES OR CHANGE POLARITY. Please reference FIG. 5.
- 2. Tuck all wires back into wiring compartment, and re-attach wiring compartment. WARNING: ENSURE ALL THJE WIRES AND CONNECTIONS ARE SEALED PROPERLY INSIDE THE FIXTURE WITHOUT PINCHING ANY WIRES.

